


QB11-W Wireless Button



Document Details

Version

V1.0 20260407

(V1.0 published 20260407)

Firmware

Firmware version can be verified on Verkada

Command command.verkada.com.

Product Models

This install guide pertains to model QB11-W-HW.

© Copyright 2026 Verkada Inc. All rights reserved.

Verkada and the Verkada logo are registered trademarks or service marks of Verkada Inc. ("Verkada"). All other trademarks are the property of their respective owners.

Verkada may make changes to this document at any time without notice. The information presented herein may be inaccurate or outdated, and Verkada is under no obligation to maintain it. ALL INFORMATION IS PROVIDED "AS-IS" AND WITHOUT ANY WARRANTIES, IMPLIED, EXPRESS, OR OTHERWISE. VERKADA DISCLAIMS LIABILITY FOR ALL DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, ARISING OUT OF USE OF THIS DOCUMENT.

Any intellectual property rights relating to Verkada products are and shall remain Verkada's exclusive property. Use of any Verkada product is subject to Verkada's end user agreement or other executed agreement with Verkada. No license, either expressed or implied, to use or distribute any Verkada product is granted under this document.

This document may not be sold, resold, licensed or sublicensed and may not be transferred without Verkada's prior written consent. No part of this document may be reproduced in whole or in part without the express written consent of Verkada.




What's in the Box




Button




Mount Plate
(Attached to device)




Wall Anchors (4
pcs)



Wood Screws
M3.5 x 20mm
(4 pcs)



L91 AA Batteries
(2 pcs)



T10 Security
Torx L-Key

Length: 20mm **Diameter:** 3.5mm
Drive: #2 Phillips

What you'll need

- Verkada VLink Hub
- A smartphone or laptop
- 1/4 inch (6.5mm) drill bit for wall anchor pilot holes
- 1/8 inch (3.2mm) drill bit for wood screw pilot holes
- #2 Phillips head screwdriver/driver bit
- Two L91 AA Batteries (included)

Connect


For easy registration and setup, scan the QR code on the product.

If you prefer to manually register your product, please proceed to:

verkada.com/start



Overview



LED Behaviors

- **Solid Green**
Button was pressed and signal was received by hub.
- ☀ **Blinking Amber**
Button was pressed, but signal has not been received by hub.

Install Mode Only

To enable Install Mode, power cycle the device by removing the battery.

- ☀ **Blinking Green**
Button was pressed and signal was received by hub.
- ☀ **Blinking Red**
Button was pressed, but signal has not been received by hub.

Technical Specifications

Battery	2x non-rechargeable Energizer Ultimate Lithium L91 AA batteries (included). <i>*5-year typical battery life.</i>
Connectivity	VLink transceiver with internal antenna (863MHz - 928MHz).
RF Range	≥ 2000ft (600m) open field line of sight range when paired with any of Verkada's VLink capable hubs (ex: BP32, BP52, BK22, BE32, WH32, WH52).
Tamper Detection	Yes, breakaway tab.
Dimensions	2.8in (L) x 2.8in (W) x 1in (H) / 70mm (L) x 70mm (W) x 26.3mm (H)
Weight	3.3oz / 95g
Operating Temp. & Humidity	32°F-122°F / 0°C-50°C, 0-90% RH non-condensing




Introduction

Mounting Positions



Above Surface



Below Surface




Wall




Installation

Preparation


Use the provided T10 Security Torx L-key to unscrew the captive security screw on the side of the product.



Remove the button from the Mount Plate.



Remove the battery pull tab.



Installation

Mounting 1/2



Place the button in the desired locations, mark the pilot hole positions.



Use a drill to make pilot holes, and screw the Mount Plate into place.

For a solid material like wood or metal, drill 1/8" (3.2mm) pilot holes.

If using wall anchors, drill 1/4" (6mm) pilot holes.




Note: The breakaway tab must be secured by a screw for the tamper detection to function.


Installation

Mounting 2/2

Engage the hook at the top of the Mount Plate and swing the button module into place.



Use the provided T10 Security Torx L-key to secure the button in place.



Appendix

Compliance

FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC Radiation Exposure Statement :

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 40cm between the radiator & your body. Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

Professional Installation:

This device must be professionally installed. The intended use is generally not for the general public. It is generally for industrial and commercial use. Installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance and other FCC rules.

Appendix

Compliance

ISED Compliance

This device complies with ISED's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

IC Radiation Exposure Statement:

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Déclaration d'exposition aux rayonnements d'IC : Cet équipement est conforme aux limites d'exposition aux rayonnements IC RSS-102 définies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20cm entre le radiateur et votre corps.

Supported Antennas:

This radio transmitter 26271-60B5901 has been approved by Innovation, Science and Economic Development Canada to operate with the antenna types listed below, with the maximum permissible gain indicated. Antenna types not included in this list that have a gain greater than the maximum gain indicated for any type listed are strictly prohibited for use with this device.

Le présent émetteur radio 26271-60B5901 a été approuvé par Innovation, Sciences et Développement économique Canada pour fonctionner avec les types d'antenne énumérés ci-dessous et ayant un gain admissible maximal. Les types d'antenne non inclus dans cette liste, et dont le gain est supérieur au gain maximal indiqué pour tout type figurant sur la liste, sont strictement interdits pour l'exploitation de l'émetteur.

Appendix

Support

Thank you for purchasing this Verkada product. If for any reason you're experiencing issues or need assistance, please contact our 24/7 Technical Support Team immediately.

Sincerely,
The Verkada Team
verkada.com/support

